



How to disable the battery saver?


iPhone

iOS 16



LOCATION


If you do not allow access to the location or enable the precise location, an alert will be displayed on the app's **Diagnostics** screen



LOCATION



In this case, select **Learn more** under Location




LOCATION





If the issue comes from a location access, follow the instructions and select **Allow the access**

LOCATION





If the issue comes from the precise location, follow the instructions and select **Use the precise location**




LOCATION

The location access must be **Always**



LOCATION

The precise location must be enabled



BATTERY



Go in phone settings and select
Battery

BATTERY



Low Power Mode must be disabled

