
How to disable the battery saver?


SAMSUNG

OneUl 6.x






Click on the gear icon to access to the Parameters











Select Your App in the list





# Uncheck Remove permission if app is unused





# Select Battery on the application details screen

14:45

Shall 66%

Shall 66%

Shall 66%

Your App

#### Unrestricted



Allow this app to use battery in the background without restrictions. This may reduce your battery life.

#### Optimised

Optimise based on your usage of this app. Recommended for most apps.

#### Restricted


Restrict battery usage while this app is running in the background. The app may not work as expected and notifications may be delayed.



#### STEP n°6





Battery use must be Unrestricted






Click on Mobile data






# Allow background data usage







Select Device care in the phone parameters menu
















## Select Background usage limits








# Disable Put unused app to sleep






Click on the symbol ...






# Select Adaptive battery







## Disable Adaptive battery



Go to the recent app, find Your App then click on the app icon at the top









A lock must be displayed at the bottom of the screen